

INC,LLC

CANopen RTC/MemModule Software Specifications

Revision	Description	Date
0.1A	Initial Specification	10/21/2003
1.1A	First Release	01/10/2004
1.2A	Added additional features. (BytesFree, BytesWritten, WriteTimeDate) 0x3012,0x3013,0x3014,0x3020	02/24/2006
1.2B	Added LED state description	11/28/2007

Table of Contents

Revision.....	2
Table of Contents.....	3
Overview:	7
Physical.....	8
Network Switch Settings:.....	8
Bit Timing Settings.....	8
LED Indicators:.....	9
Supported SDO abort codes.....	11
Supported Emergency Error Codes.....	12
Emergency Object Data.....	13
Pre-defined connection set.....	14
Identifier allocation scheme for the pre-defined connection set.....	14
Broadcast Objects of the Pre-defined Connection Set.....	14
Peer-to-Peer Objects of the Pre-defined Connection Set.....	14
Assigning COB-IDS.....	14
Object Dictionary Data Types.....	15
Object Dictionary Structure.....	16
Object Dictionary Overview.....	17
Object Dictionary Entries for Communication.....	17
Standard Objects.....	17
Server SDO Parameter.....	17
Client SDO Parameter.....	17
Receive PDO Communication Parameter.....	18
Receive PDO Mapping Parameter.....	18
Transmit PDO Communication Parameter.....	18
Transmit PDO Mapping Parameter.....	18
Detailed Specification of Communication Profile Specific Objects.....	20
Object 1000h: Device Type.....	20
OBJECT DESCRIPTION.....	20
ENTRY DESCRIPTION.....	20
Object 1001h: Error Register.....	21
OBJECT DESCRIPTION.....	21
ENTRY DESCRIPTION.....	21
Object 1002h: Manufacturer Status Register.....	22
OBJECT DESCRIPTION.....	22
ENTRY DESCRIPTION.....	22
Object 1003h: Pre-defined Error Field.....	23
OBJECT DESCRIPTION.....	23
ENTRY DESCRIPTION.....	23
Object 1005h: COB-ID SYNC message.....	24
OBJECT DESCRIPTION.....	24
ENTRY DESCRIPTION.....	24
Object 1008h: Manufacturer Device Name.....	25
OBJECT DESCRIPTION.....	25
ENTRY DESCRIPTION.....	25
Object 1009h: Manufacturer Hardware Version.....	26
OBJECT DESCRIPTION.....	26
ENTRY DESCRIPTION.....	26
Object 100Ah: Manufacturer Software Version.....	27
OBJECT DESCRIPTION.....	27
ENTRY DESCRIPTION.....	27

Object 100Ch: Guard Time.....	28
OBJECT DESCRIPTION.....	28
ENTRY DESCRIPTION.....	28
Object 100Dh: Life Time Factor.....	29
OBJECT DESCRIPTION.....	29
ENTRY DESCRIPTION.....	29
Object 1010h: Store parameters.....	30
OBJECT DESCRIPTION.....	31
ENTRY DESCRIPTION.....	31
Object 1011h: Restore default parameters.....	33
OBJECT DESCRIPTION.....	34
ENTRY DESCRIPTION.....	34
Object 1012h: COB-ID Time Stamp Object.....	35
OBJECT DESCRIPTION.....	35
ENTRY DESCRIPTION.....	35
Object 1014h: COB-ID Emergency Object.....	36
OBJECT DESCRIPTION.....	37
ENTRY DESCRIPTION.....	37
Object 1015h: Inhibit Time EMCY.....	38
OBJECT DESCRIPTION.....	38
ENTRY DESCRIPTION.....	38
Object 1016h: Consumer Heartbeat Time.....	39
Value	39
OBJECT DESCRIPTION.....	39
ENTRY DESCRIPTION.....	39
Object 1017h: Producer Heartbeat Time	40
OBJECT DESCRIPTION.....	40
ENTRY DESCRIPTION.....	40
Object 1018h: Identity Object.....	41
OBJECT DESCRIPTION.....	41
ENTRY DESCRIPTION.....	41
Object 1020h: Verify Configuration.....	43
Object 1029: Error behavior object.....	44
OBJECT DESCRIPTION.....	44
ENTRY DESCRIPTION.....	44
Object 1200h-1201h: Server SDO Parameter.....	45
ENTRY DESCRIPTION.....	46
Object 1400h – 141Eh: Receive PDO Communication Parameter.....	47
OBJECT DESCRIPTION.....	49
ENTRY DESCRIPTION.....	49
Object 1600h – 161Eh: Receive PDO Mapping Parameter.....	51
OBJECT DESCRIPTION.....	52
ENTRY DESCRIPTION.....	52
Object 1800h – 181Fh: Transmit PDO Communication Parameter.....	53
OBJECT DESCRIPTION.....	53
ENTRY DESCRIPTION.....	53
Object 1A00h – 1A1Fh: Transmit PDO Mapping Parameter.....	55
OBJECT DESCRIPTION.....	55
ENTRY DESCRIPTION.....	55
Multiplexed PDOs.....	56
MPDO Protocol.....	56
Destination Address Mode (DAM).....	56
Source Address Mode (SAM).....	56
Object dictionary entries.....	57
PDO Mapping Record.....	57
Additional error code meanings.....	58

Predefinitions.....	58
Introduction.....	58
PDO Mapping.....	59
6.2.1 1st RPDO mapping (Memory Access).....	59
6.2.2 1st TPDO mapping (Memory Access).....	59
Manufacturer Specific Objects.....	60
Overview:.....	60
RTC Objects.....	60
Type.....	60
Access.....	60
I/O.....	60
NV.....	60
Memory Objects.....	60
Type.....	60
Access.....	60
I/O.....	60
NV.....	60
CANopen Objects.....	60
Type.....	60
Access.....	60
I/O.....	60
NV.....	60
Manufacturer Specific Object Details:.....	61
RTC Objects.....	61
Object 2000h: Time Of Day.....	61
OBJECT DESCRIPTION.....	61
ENTRY DESCRIPTION.....	61
Object 2001h: Time Date (Reserved for Future Use).....	62
OBJECT DESCRIPTION.....	62
ENTRY DESCRIPTION.....	62
Object 2002h: Time String.....	63
OBJECT DESCRIPTION.....	63
ENTRY DESCRIPTION.....	63
Object 2003h: Date String.....	64
OBJECT DESCRIPTION.....	64
ENTRY DESCRIPTION.....	64
Object 2004h: Time String Format.....	65
OBJECT DESCRIPTION.....	65
ENTRY DESCRIPTION.....	65
Object 2005h: Date String Format.....	66
OBJECT DESCRIPTION.....	66
ENTRY DESCRIPTION.....	66
Memory Objects.....	67
Object 3000h: Memory Erase.....	67
OBJECT DESCRIPTION.....	67
ENTRY DESCRIPTION.....	67
Object 3001h: Memory Write.....	68
OBJECT DESCRIPTION.....	68
ENTRY DESCRIPTION.....	68
Object 3002h: Memory Read.....	69
OBJECT DESCRIPTION.....	69
ENTRY DESCRIPTION.....	69
Object 3003h: Memory Read Reset.....	70
OBJECT DESCRIPTION.....	70
ENTRY DESCRIPTION.....	70
Object 3004h: Memory Store Mode.....	71

OBJECT DESCRIPTION.....	71
ENTRY DESCRIPTION.....	71
Object 3005h: Memory Delimiter.....	72
OBJECT DESCRIPTION.....	72
ENTRY DESCRIPTION.....	72
Object 3006h: Memory Fixed Length.....	73
OBJECT DESCRIPTION.....	73
ENTRY DESCRIPTION.....	73
Object 3007h: Memory AutoStamp Format.....	74
OBJECT DESCRIPTION.....	74
ENTRY DESCRIPTION.....	74
Object 3008h: Memory Blank.....	75
OBJECT DESCRIPTION.....	75
ENTRY DESCRIPTION.....	75
Object 3010h: Memory Request Fragment (Reserved).....	76
OBJECT DESCRIPTION.....	76
ENTRY DESCRIPTION.....	76
Object 3011h: Memory Response Fragment (Reserved).....	77
OBJECT DESCRIPTION.....	77
ENTRY DESCRIPTION.....	77
Object 3012h: Memory Overwrite Mode.....	78
OBJECT DESCRIPTION.....	78
ENTRY DESCRIPTION.....	78
Object 3013h: Memory Bytes Written.....	79
OBJECT DESCRIPTION.....	79
ENTRY DESCRIPTION.....	79
Object 3014h: Memory Bytes Free.....	80
OBJECT DESCRIPTION.....	80
ENTRY DESCRIPTION.....	80
Object 3020h: Write Time/Date Stamp to Memory.....	81
OBJECT DESCRIPTION.....	81
ENTRY DESCRIPTION.....	81
CANopen Objects.....	82
Object 4000h: CANopen Baud Rate.....	82
OBJECT DESCRIPTION.....	82
ENTRY DESCRIPTION.....	82
Object 4001h: CANopen NodeID.....	83
OBJECT DESCRIPTION.....	83
ENTRY DESCRIPTION.....	83

Overview:

The INC RTC/Memory Module allows the user of a CANopen network to store and retrieve data and the actual time and date. The RTC/Memory Module maintains the time and date during power down using an internal battery. The time and date can be read in the CANopen defined TIME_OF_DAY format or read/written in ASCII format. The user can store data to and retrieve data from the internal flash memory. The memory features allow the RTC/Memory module to act like a file storage device. Internal read and write file pointers automatically advance after a read or write to free the user to read and write data without having to worry about internal addressing. The RTC/Memory Module can store up to 392k. Memory writes are buffered in RAM and then maintained in flash memory for further data protection.

The RTC/Memory Module includes a Windows based configuration tool that allows the time and date to be set and retrieved, configuration to be set, and memory contents uploaded to a file. The configuration can then be downloaded to the display using one of several supported CANopen interface cards. The RTC/Memory Module can also be configured using the included EDS file or through SDO commands. The RTC/Memory Module can support up to 4 TxPDOs and 4 RxPDOS.

Physical

Network Switch Settings:

There are no switches to set the network ID and baud. This must be done through CANopen or RS232 or USB.

Bit Timing Settings

Bit rate Bus length (1)	Nominal bit time t_b	Number of time quanta per bit	Length of time quantum t_q	Location of sample point
1 Mbit/s 25 m	1 us	8	125 ns	6 tq(750 ns)
800 kbit/s 50 m	1,25 us	10	125 ns	8 tq(1 us)
500 kbit/s 100 m	2 us	16	125 ns	14 tq(1,75 us)
250 kbit/s 250 m(2)	4 us	16	250 ns	14 tq(3,5 us)
125 kbit/s 500 m(2)	8 us	16	500 ns	14 tq(7 us)
50 kbit/s 1000 m(3)	20 us	16	1,25 us	14 tq(17,5 us)
20 kbit/s 2500 m(3)	50 us	16	3,125 us	14 tq(43,75 us)
10 kbit/s 5000 m(3)	100 us	16	6,25 us	14 tq(87,5 us)

LED Indicators:

Two LEDs are used to indicate the status of the module, these are the NET and MOD leds.

CAN LED

CAN RUN LED State (GREEN)	Module State	Description
Single Flash	STOPPED	The Device is in the stopped state.
Blinking	PRE-OPERATIONAL	The Device is in the Pre-Operational State
On	OPERATIONAL	The Device is in the Operational State.

CAN ERROR LED State (RED)	Module State	Description
Off	no error	The Device is in working condition.
Single Flash	warning limit reached	At least one of the error counters of the CAN controller has reached or exceeded the warning level (too many error frames).
Double Flash	Error Control Event	A guard event (NMT-Slave or NMT-master) or a heartbeat event (Heartbeat consumer) has occurred.
Triple Flash	Sync Error	The SYNC message has not been received within the configured communication cycle period time out (see Object Dictionary Entry 0x1006).
On	Bus Off	The CAN controller is bus off

Note: The green and red led are independent and can be turned on together causing an orange appearance.

MOD LED

MOD LED State	Module State	Description
OFF	NO POWER	There is no power applied to the module.
Green On	No Module Error	The Device is operating properly.
Red Flashing	Minor Fault	The device has experienced a minor fault. This includes power issues, running out of memory, etc. This usually means that the module must be reset.
Red On	Major Fault	The Device has experienced a major fault. This can include a program checksum error, etc. This usually means module needs to be replaced.

Note: Both Leds CAN and MOD will flash red orange when in the download mode.

Supported SDO abort codes

Abort code	Description
0503 0000h	Toggle bit not alternated.
0504 0000h	SDO protocol timed out.
0504 0001h	Client/server command specifier not valid or unknown.
0504 0002h	Invalid block size (block mode only).
0504 0003h	Invalid sequence number (block mode only).
0504 0004h	CRC error (block mode only).
0504 0005h	Out of memory.
0601 0000h	Unsupported access to an object.
0601 0001h	Attempt to read a write only object.
0601 0002h	Attempt to write a read only object.
0602 0000h	Object does not exist in the object dictionary.
0604 0041h	Object cannot be mapped to the PDO.
0604 0042h	The number and length of the objects to be mapped would exceed PDO length.
0604 0043h	General parameter incompatibility reason.
0604 0047h	General internal incompatibility in the device.
0606 0000h	Access failed due to an hardware error.
0607 0010h	Data type does not match, length of service parameter does not match
0607 0012h	Data type does not match, length of service parameter too high
0607 0013h	Data type does not match, length of service parameter too low
0609 0011h	Sub-index does not exist.

The abort codes not listed here are reserved.

Supported Emergency Error Codes

Error Code (hex)	Meaning
00xx	Error Reset or No Error
10xx	Generic Error
81xx	Communication
8110	CAN Overrun (Objects lost)
8120	CAN in Error Passive Mode
8130	Life Guard Error or Heartbeat Error
8140	Recovered from bus off
8150	Transmit COB-ID
82xx	Protocol Error
8210	PDO not processed due to length error
8220	PDO length exceeded
FFxx	Device specific

Emergency Object Data

The Emergency Telegram consists of 8 bytes with the data as shown in

Emergency Object

Byte	0	1	2	3	4	5	6	7
Content	Emergency Error Code (see Table)	Error register (Object 1001H)	TBD	TBD	TBD			

Pre-defined connection set

Bit Number: COB-Identifier

10	9	8	7	6	5	4	3	2	1	0
Function Code						Node-ID				

Identifier allocation scheme for the pre-defined connection set

Broadcast Objects of the Pre-defined Connection Set

Object	function code(binary)	resulting COB-ID	Communication Parameters at Index
NMT	0000	0	-
SYNC	0001	128 (80h)	1005h,1006h,1007h
TIME STAMP	0010	256 (100h)	1012h, 1013h

Peer-to-Peer Objects of the Pre-defined Connection Set

object	function code (binary)	Resulting COB-IDs	Communication Parameters at Index
EMERGENCY	0001	129 (81h) - 255 (FFh)	1014h, 1015h
PDO1 (tx)	0011	385 (181h) - 511 (1FFh)	1800h
PDO1 (rx)	0100	513 (201h) - 639 (27Fh)	1400h
PDO2 (tx)	0101	641 (281h) - 767 (2FFh)	1801h
PDO2 (rx)	0110	769 (301h) - 895 (37Fh)	1401h
PDO3 (tx)	0111	897 (381h) - 1023 (3FFh)	1802h
PDO3 (rx)	1000	1025 (401h) - 1151 (47Fh)	1402h
PDO4 (tx)	1001	1153 (481h) - 1279 (4FFh)	1803h
PDO4 (rx)	1010	1281 (501h) - 1407 (57Fh)	1403h
SDO (tx)	1011	1409 (581h) - 1535 (5FFh)	1200h
SDO (rx)	1100	1537 (601h) - 1663 (67Fh)	1200h
NMT Error Control	1110	1793 (701h) - 1919 (77Fh)	1016h, 1017h

Seen from the device's point of view.

The pre-defined connection set always applies to the standard CAN frame with 11-bit Identifier, even if extended CAN frames are present in the network.

Assigning COB-IDS

When Assigning COB-Ids to SDO and PDO objects, the user should use care. If the user selects a COB-ID for a PDO that is already assigned to the display's SDO by the pre-defined connection set, the RTC/Memory Module will accept the COB-ID, but the module may not function as the user desires. The COB-ID acceptance is done in order to provide greater flexibility for the advanced user.

Object Dictionary Data Types

Index	Object	Name
0001	DEFTYPE	BOOLEAN
0002	DEFTYPE	INTEGER8
0003	DEFTYPE	INTEGER16
0004	DEFTYPE	INTEGER32
0005	DEFTYPE	UNSIGNED8
0006	DEFTYPE	UNSIGNED16
0007	DEFTYPE	UNSIGNED32
0008	DEFTYPE	REAL32
0009	DEFTYPE	VISIBLE_STRING
000A	DEFTYPE	OCTET_STRING
000B	DEFTYPE	UNICODE_STRING
000C	DEFTYPE	TIME_OF_DAY
000D	DEFTYPE	TIME_DIFFERENCE
000E	reserved	-
000F	DEFTYPE	DOMAIN
0010	DEFTYPE	INTEGER24
0011	DEFTYPE	REAL64
0012	DEFTYPE	INTEGER40
0013	DEFTYPE	INTEGER48
0014	DEFTYPE	INTEGER56
0015	DEFTYPE	INTEGER64
0016	DEFTYPE	UNSIGNED24
0017	reserved	-
0018	DEFTYPE	UNSIGNED40
0019	DEFTYPE	UNSIGNED48
001A	DEFTYPE	UNSIGNED56
001B	DEFTYPE	UNSIGNED64
001C-001F	reserved	-
0020	DEFSTRUCT	PDO_COMMUNICATION_PARAMETER
0021	DEFSTRUCT	PDO_MAPPING
0022	DEFSTRUCT	SDO_PARAMETER
0023	DEFSTRUCT	IDENTITY
0024-003F	reserved	-
0040-005F	DEFSTRUCT	Manufacturer Specific Complex Data Types
0060-007F	DEFTYPE	Device Profile (0) Specific Standard Data Types
0080-009F	DEFSTRUCT	Device Profile (0) Specific Complex Data Types
00A0-00BF	DEFTYPE	Device Profile 1 Specific Standard Data Types
00C0-00DF	DEFSTRUCT	Device Profile 1 Specific Complex Data Types
00E0-00FF	DEFTYPE	Device Profile 2 Specific Standard Data Types
0100-011F	DEFSTRUCT	Device Profile 2 Specific Complex Data Types
0120-013F	DEFTYPE	Device Profile 3 Specific Standard Data Types
0140-015F	DEFSTRUCT	Device Profile 3 Specific Complex Data Types
0160-017F	DEFTYPE	Device Profile 4 Specific Standard Data Types
0180-019F	DEFSTRUCT	Device Profile 4 Specific Complex Data Types
01A0-01BF	DEFTYPE	Device Profile 5 Specific Standard Data Types
01C0-01DF	DEFSTRUCT	Device Profile 5 Specific Complex Data Types
01E0-01FF	DEFTYPE	Device Profile 6 Specific Standard Data Types
0200-021F	DEFSTRUCT	Device Profile 6 Specific Complex Data Types
0220-023F	DEFTYPE	Device Profile 7 Specific Standard Data Types
0240-025F	DEFSTRUCT	Device Profile 7 Specific Complex Data Types

Object Dictionary Structure

Index (hex)	Object
0000	not used
0001-001F	Static Data Types
0020-003F	Complex Data Types
0040-005F	Manufacturer Specific Complex Data Types
0060-007F	Device Profile Specific Static Data Types
0080-009F	Device Profile Specific Complex Data Types
00A0-0FFF	Reserved for further use
1000-1FFF	Communication Profile Area
2000-5FFF	Manufacturer Specific Profile Area
6000-9FFF	Standardized Device Profile Area
A000-FFFF	Reserved for further use

Object Dictionary Overview

Object Dictionary Entries for Communication

Standard Objects

Index(hex)	Object (Symbolic Name)	Name	Type	Acc. 1	M/O
1000	VAR	device type	UNSIGNED32	ro	M
1001	VAR	error register	UNSIGNED8	ro	M
1002	VAR	Manufacturer status register	UNSIGNED32	ro	O
1003	VAR	Pre-defined error field	UNSIGNED32	Ro	O
1005	VAR	COB-ID SYNC	UNSIGNED32	rw	O
1008	VAR	Manufacturer device name	Vis-String	const	O
1009	VAR	Manufacturer hardware version	Vis-String	const	O
100A	VAR	Manufacturer software version	Vis-String	const	O
100C	VAR	guard time	UNSIGNED16	rw	O
100D	VAR	life time factor	UNSIGNED8	rw	O
1010	ARRAY	store parameters	UNSIGNED32	rw	O
1011	ARRAY	restore default parameters	UNSIGNED32	rw	O
1012	VAR	COB-ID TIME	UNSIGNED32	rw	O
1014	VAR	COB-ID EMCY	UNSIGNED32	rw	O
1015	VAR	Inhibit Time EMCY	UNSIGNED16	rw	O
1016	ARRAY	Consumer heartbeat time	UNSIGNED32	RW	O
1017	VAR	Producer heartbeat time	UNSIGNED16	rw	O
1018	RECORD	Identity Object	Identity (23h)	ro	M
1020	ARRAY	Verify Configuration	UNSIGNED32	rw	O
1029	ARRAY	Error Behavior	UNSIGNED8	rw	O

Server SDO Parameter

1200	RECORD	1 st Server SDO parameter	SDO Parameter (22h)	ro	O
1201	RECORD	2 nd Server SDO parameter	SDO Parameter (22h)	rw	O

Client SDO Parameter

Not Supported

Receive PDO Communication Parameter

1400	RECORD	1 st receive PDO Parameter	PDO CommPar (20h)	rw	M/O*
1401	RECORD	2 nd receive PDO Parameter	PDO CommPar (20h)	rw	M/O*
:::::	:::::	:::::	:::::	:::::	:::::
141F	RECORD	32 nd receive PDO Parameter	PDO CommPar (20h)	rw	M/O*

Receive PDO Mapping Parameter

1600	RECORD	1 st receive PDO mapping	PDO Mapping (21h)	rw	M/O*
1601	RECORD	2 nd receive PDO mapping	PDO Mapping (21h)	rw	M/O*
:::::	:::::	:::::	:::::	:::::	:::::
161F	RECORD	32 nd receive PDO mapping	PDO Mapping (21h)	rw	M/O*

Transmit PDO Communication Parameter

1800	RECORD	1 st transmit PDO Parameter	PDO CommPar (20h)	rw	M/O*
1801	RECORD	2 nd transmit PDO Parameter	PDO CommPar (20h)	rw	M/O*
:::::	:::::	:::::	:::::	:::::	:::::
181F	RECORD	32 nd transmit PDO Parameter	PDO CommPar (20h)	rw	M/O*

Transmit PDO Mapping Parameter

1A00	RECORD	1 st transmit PDO mapping	PDO Mapping (21h)	rw	M/O*
1A01	RECORD	2 nd transmit PDO mapping	PDO Mapping (21h)	rw	M/O*
:::::	:::::	:::::	:::::	:::::	:::::
1A1F	RECORD	32 nd transmit PDO mapping	PDO Mapping (21h)	rw	M/O*

Ranges 1600-161Fh and 1A00-1A1Fh can also be used to map multiplexed PDOs. See specification below.

Detailed Specification of Communication Profile Specific Objects

Object 1000h: Device Type

Contains information about the device type. The object at index 1000h describes the type of device and its functionality. It is composed of a 16-bit field which describes the device profile that is used and a second 16-bit field which gives additional information about optional functionality of the device. The Additional Information parameter is device profile specific.

OBJECT DESCRIPTION

INDEX	1000h
Name	device type
Object Code	VAR
Data Type	UNSIGNED32
Category	Mandatory

ENTRY DESCRIPTION

Access	Ro
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	No

Byte:

MSB	LSB
Additional Information	Device Profile Number
0x0000	0x0000

Object 1001h: Error Register

This object is an error register for the device. The device can map internal errors in this byte. This entry is mandatory for all devices. It is a part of an Emergency object.

OBJECT DESCRIPTION

INDEX	1001h
Name	error register
Object Code	VAR
Data Type	UNSIGNED8
Category	Mandatory

ENTRY DESCRIPTION

Access	ro
PDO Mapping	Optional
Value Range	UNSIGNED8
Default Value	No

Structure of the Error Register

Bit	M/O	Supported	Meaning
0	M	Yes	generic error
1	O	No	Current
2	O	Yes	Voltage
3	O	No	Temperature
4	O	Yes	communication error (overrun, error state)
5	O	No	device profile specific
6	O	No	Reserved (always 0)
7	O	Yes	manufacturer specific

If a bit is set to 1 the specified error has occurred. The generic error is signaled at any error situation.

Object 1002h: Manufacturer Status Register

This object is a common status register for manufacturer specific purposes. In this document only the size and the location of this object is defined.

OBJECT DESCRIPTION

INDEX	1002h
Name	manufacturer status register
Object Code	VAR
Data Type	UNSIGNED32
Category	Optional

ENTRY DESCRIPTION

Access	ro
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	No

MSB

LSB

--	--	--	--

Object 1003h: Pre-defined Error Field

The object at index 1003h holds the errors that have occurred on the device and have been signaled via the Emergency Object. In doing so it provides an error history.

1. The entry at sub-index 0 contains the number of actual errors that are recorded in the array starting at sub-index 1.
2. Every new error is stored at sub-index 1, the older ones move down the list.
3. Writing a "0" to sub-index 0 deletes the entire error history (empties the array). Values higher than 0 are not allowed to write. This has to lead to an abort message (error code: 0609 0030h).
4. The error numbers are of type UNSIGNED32 (see Table 7-18) and are composed of a 16 bit error code and a 16 bit additional error information field which is manufacturer specific. The error code is contained in the lower 2 bytes (LSB) and the additional information is included in the upper 2 bytes (MSB). The additional information consists of the information contained in the Error register Object (1001h). The length entry on sub-index 0h and at least one error entry at sub-index 1H.

Byte: MSB LSB

Additional Information	Error code
Structure of the pre-defined error field	

OBJECT DESCRIPTION

INDEX	1003h
Name	pre-defined error field
Object Code	ARRAY
Data Type	UNSIGNED32
Category	Optional

ENTRY DESCRIPTION

Sub-Index	0h
Description	number of errors
Entry Category	Mandatory
Access	rw
PDO Mapping	No
Value Range	0 - 10
Default Value	0

Sub-Index	1h
Description	standard error field
Entry Category	Optional
Access	ro
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	No

Sub-Index	2h – 10
Description	standard error field
Entry Category	Optional
Access	ro
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	No

Object 1005h: COB-ID SYNC message

Index 1005h defines the COB-ID of the Synchronization Object (SYNC). Further, it defines whether the device generates the SYNC.

UNSIGNED32

MSB LSB

bits	31	30	29	28-11	10-0
11-bit-ID	X	0/1	0	0 0	11-bit Identifier
29-bit-ID	X	0/1	1	29 -bit Identifier	

Structure of SYNC COB-ID entry

Description of SYNC COB-ID entry

bit number	value	meaning
31 (MSB)	X	do not care
30	0	Device does not generate SYNC message
	1	Device generates SYNC message
29	0	11-bit ID (CAN 2.0A)
	1	29-bit ID (CAN 2.0B)
28 – 11	0 X	if bit 29=0 if bit 29=1: bits 28-11 of 29-bit-SYNC-COB-ID
10-0 (LSB)	X	bits 10-0 of SYNC-COB-ID

Bits 29, 30 may be static (not changeable). If a device is not able to generate SYNC messages, an attempt to set bit 30 is responded with an abort message (abort code: 0609 0030h). Devices supporting the standard CAN frame type only either ignore attempts to change bit 29 or respond with an abort message (abort code: 0609 0030h). The first transmission of SYNC object starts within 1 sync cycle after setting Bit 30 to 1. It is not allowed to change Bit 0-29, while the objects exist (Bit 30=1).

OBJECT DESCRIPTION

INDEX	1005h
Name	COB-ID SYNC
Object Code	VAR
Data Type	UNSIGNED32
Category	Conditional;Mandatory, if PDO communication on a synchronous base is supported

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	80h or 8000 0080h

Object 1008h: Manufacturer Device Name

Contains the manufacturer device name.

OBJECT DESCRIPTION

INDEX	1008h
Name	manufacturer device name
Object Code	VAR
Data Type	Visible String
Category	Optional

ENTRY DESCRIPTION

Access	const
PDO Mapping	No
Value Range	No
Default Value	CANopen RTC/MemModule

Object 1009h: Manufacturer Hardware Version

Contains the manufacturer hardware version description.

OBJECT DESCRIPTION

INDEX	1009h
Name	manufacturer hardware version
Object Code	VAR
Data Type	Visible String
Category	Optional

ENTRY DESCRIPTION

Access	const
PDO Mapping	No
Value Range	No
Default Value	01

Object 100Ah: Manufacturer Software Version

Contains the manufacturer software version description.

OBJECT DESCRIPTION

INDEX	100Ah
Name	Manufacturer software version
Object Code	VAR
Data Type	Visible String
Category	Optional

ENTRY DESCRIPTION

Access	Const
PDO Mapping	No
Value Range	No
Default Value	1.01

Object 100Ch: Guard Time

The objects at index 100Ch and 100Dh include the guard time in milliseconds and the life time factor.

The life time factor multiplied with the guard time gives the life time for the Life Guarding Protocol. It is 0 if not used.

OBJECT DESCRIPTION

INDEX	100Ch
Name	guard time
Object Code	VAR
Data Type	UNSIGNED16
Category	Conditional; Mandatory, if heartbeat is not supported

ENTRY DESCRIPTION

Access	rw
PDO Mapping	No
Value Range	UNSIGNED16
Default Value	0

Object 100Dh: Life Time Factor

The life time factor multiplied with the guard time gives the life time for the node guarding protocol. It is 0 if not used.

OBJECT DESCRIPTION

INDEX	100Dh
Name	life time factor
Object Code	VAR
Data Type	UNSIGNED8
Category	Conditional; Mandatory, if heartbeat is not supported

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	UNSIGNED8
Default Value	0

Object 1010h: Store parameters

This object supports the saving of parameters in non volatile memory. By read access the device provides information about its saving capabilities. Several parameter groups are distinguished:

Sub-Index 0 contains the largest Sub-Index that is supported.

Sub-Index 1 refers to all parameters that can be stored on the device.

Sub-Index 2 refers to communication related parameters (Index 1000h - 1FFFh manufacturer specific communication parameters).

Sub-Index 3 refers to application related parameters (Index 6000h - 9FFFh manufacturer specific application parameters).

At Sub-Index 4 - 127 manufacturers may store their choice of parameters individually.

Sub-Index 128 - 254 are reserved for future use.

In order to avoid storage of parameters by mistake, storage is only executed when a specific signature is written to the appropriate Sub-Index. The signature is "save".

Signature MSB LSB

ISO 8859

("ASCII")

hex

E	V	a	s
65h	76h	61h	73h

Storage write access signature

On reception of the correct signature in the appropriate sub-index the device stores the parameter and then confirms the SDO transmission (initiate download response). If the storing failed, the device responds with an Abort SDO Transfer (abort code: 0606 0000h).

If a wrong signature is written, the device refuses to store and responds with Abort SDO Transfer (abort code: 0800 002xh).

On read access to the appropriate Sub-Index the device provides information about its storage functionality with the following format:

UNSIGNED32

MSB

LSB

31-2	1	0
reserved (=0)	0/1	0/1

Storage read access structure

Structure of read access

bit number	Value	meaning
31-2	0	reserved (=0)
1	0	Device does not save parameters autonomously
	1	Device saves parameters autonomously
0	0	Device does not save parameters on command
	1	Device saves parameters on command

Autonomous saving means that a device stores the storable parameters in a non-volatile manner without user request.

OBJECT DESCRIPTION

INDEX	1010h
Name	store parameters
Object Code	ARRAY
Data Type	UNSIGNED32
Category	Optional

ENTRY DESCRIPTION

Sub-Index	0h
Description	largest subindex supported
Entry Category	Mandatory
Access	ro
PDO Mapping	No
Value Range	1h - 7Fh
Default Value	4

Sub-Index	1h
Description	Save all parameters
Entry Category	Mandatory
Access	Rw
PDO Mapping	No
Value Range	UNSIGNED32 (Figure 55 for write access; Figure 56 for read access)
Default Value	01h

Sub-Index	2h
Description	save communication parameters
Entry Category	Optional
Access	rw
PDO Mapping	No
Value Range	UNSIGNED32 (Figure 55 for write access; Figure 56 for read access)
Default Value	01h

Sub-Index	3h
Description	Save application parameters
Entry Category	Optional
Access	Rw
PDO Mapping	No
Value Range	UNSIGNED32 (Figure 55 for write access; Figure 56 for read access)
Default Value	02h

Sub-Index	4h
Description	Save I/O Configuration and Node Address
Entry Category	Optional
Access	Rw
PDO Mapping	No
Value Range	UNSIGNED32 (Figure 55 for write access; Figure 56 for read access)
Default Value	01h

Note Application parameters are stored autonomously. Communication parameters must be manually stored.

Object 1011h: Restore default parameters

With this object the default values of parameters according to the communication or device profile are restored. By read access the device provides information about its capabilities to restore these values.

Several parameter groups are distinguished:

Sub-Index 0 contains the largest Sub-Index that is supported.

Sub-Index 1 refers to all parameters that can be restored.

Sub-Index 2 refers to communication related parameters (Index 1000h - 1FFFh manufacturer specific communication parameters).

Sub-Index 3 refers to application related parameters (Index 6000h - 9FFFh manufacturer specific application parameters).

At Sub-Index 4 - 127 manufacturers may restore their individual choice of parameters.

Sub-Index 128 - 254 are reserved for future use.

In order to avoid the restoring of default parameters by mistake, restoring is only executed when a specific signature is written to the appropriate sub-index. The signature is "load".

Signature MSB LSB

ASCII

Hex

d	a	o	l
64h	61h	6Fh	6Ch

Figure 57: Restoring write access signature

On reception of the correct signature in the appropriate sub-index the device restores the default parameters and then confirms the SDO transmission (initiate download response). If the restoring failed, the device responds with an Abort SDO Transfer (abort code: 0606 0000h). If a wrong signature is written, the device refuses to restore the defaults and responds with an Abort SDO Transfer (abort code: 0800 002xh).

The default values are set valid after the device is reset (reset node for sub-index 1h - 7Fh, reset communication for sub-index 2h) or power cycled.

On read access to the appropriate sub-index the device provides information about its default parameter restoring capability with the following format:

UNSIGNED32

MSB	LSB
31-1	0
Reserved (=0)	0/1

Figure 59: Restoring default values read access structure

Table 50: Structure of restore read access

bit number	value	meaning
31-1	0	reserved (=0)
0	0	Device does not restore default parameters
	1	Device restores parameters

OBJECT DESCRIPTION

Index	1011h
Name	restore default parameters
Object Code	ARRAY
Data Type	UNSIGNED32
Category	Optional

ENTRY DESCRIPTION

Sub-Index	0h
Description	largest subindex supported
Entry Category	Mandatory
Access	ro
PDO Mapping	No
Value Range	1h- 7Fh
Default Value	4

Sub-Index	1h
Description r	Restore all default parameters
Entry Category	Mandatory
Access	Rw
PDO Mapping	No
Value Range	UNSIGNED32 (Figure 57)
Default Value	01h

Sub-Index	2h
Description	Restore communication default parameters
Entry Category	Optional
Access	Rw
PDO Mapping	No
Value Range	UNSIGNED32 (Figure 57)
Default Value	01h

Sub-Index	3h
Description	Restore application default parameters
Entry Category	Optional
Access	Rw
PDO Mapping	No
Value Range	UNSIGNED32 (Figure 57)
Default Value	01h

Sub-Index	4h
Description	Restore Manufacturer Specific parameters
Entry Category	Optional
Access	Rw
PDO Mapping	No
Value Range	UNSIGNED32 (Figure 57)
Default Value	01h

The number and type of physically attached modules control most of the manufacturer specific parameters, therefore Sub-Index 4 is reserved for future use.

Object 1012h: COB-ID Time Stamp Object

Index 1012h defines the COB-ID of the Time-Stamp Object (TIME). Further, it defines whether the device consumes the TIME or whether the device generates the TIME. The structure of this object is shown in Figure 60 and Table 51.

UNSIGNED32
MSB LSB

bits	31	30	2 9	28-11	10-0
11-bit-ID	0/1	0/1	0	0 0	11-bit Identifier
29-bit-ID	0/1	0/1	1		29-bit Identifier

Figure 60: Structure of TIME COB-ID entry

Table 51: Description of TIME COB-ID entry

bit number	value	meaning
31 (MSB)	0	Device does not consume TIME message
	1	Device consumes TIME message
30	0	Device does not produce TIME message
	1	Device produces TIME message
29	0	11-bit ID (CAN 2.0A)
	1	29-bit ID (CAN 2.0B)
28 – 11	0	if bit 29=0
	X	if bit 29=1: bits 28-11 of 29-bit-TIME-COB-ID
10-0 (LSB)	X	bits 10-0 of TIME-COB-ID

Bits 29, 30 may be static (not changeable). If a device is not able to generate TIME messages, an attempt to set bit 30 is responded with an abort message (abort code: 0609 0030h). Devices supporting the standard CAN frame type only, an attempt to set bit 29 is responded with an abort message (abort code: 0609 0030h). It is not allowed to change Bits 0-29, while the object exists (Bit 30=1).

OBJECT DESCRIPTION

INDEX	1012h
Name	COB-ID time stamp message
Object Code	VAR
Data Type	UNSIGNED32
Category	Optional

ENTRY DESCRIPTION

Access	rw
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	100h

Object 1014h: COB-ID Emergency Object

Index 1014h defines the COB-ID of the Emergency Object (EMCY). The structure of this object is shown in Figure 61.

UNSIGNED32

MSB LSB

<i>Bits</i>	31	30	29	28-11	10-0
11-bit-ID	0/1	0	0	0 0	11-bit Identifier
29-bit-ID	0/1	0	1	29 -bit Identifier	

Figure 61: Structure of the EMCY Identifier entry

Table 52: Description of EMCY COB-ID entry

bit number	value	Meaning
31 (MSB)	0	EMCY exists / is valid
	1	EMCY does not exist / is not valid
30	0	reserved (always 0)
29	0	11-bit ID (CAN 2.0A)
	1	29-bit ID (CAN 2.0B)
28 - 11	0	if bit 29=0
	X	if bit 29=1: bits 28-11 of 29-bit-COB-ID
10-0 (LSB)	X	bits 10-0 of COB-ID

Devices supporting the standard CAN frame type only, an attempt to set bit 29 is responded with an abort message (abort code: 0609 0030h). It is not allowed to change Bits 0-29, while the object exists (Bit 31=0).

OBJECT DESCRIPTION

INDEX	1014h
Name	COB-ID Emergency message
Object Code	VAR
Data Type	UNSIGNED32
Category	Conditional;Mandatory, if Emergency is supported

ENTRY DESCRIPTION

Access	ro;optional rw
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	80h + Node-ID

Object 1015h: Inhibit Time EMCY

The inhibit time for the EMCY message can be adjusted via this entry. If this entry exists it must be writeable in the object dictionary. The time has to be a multiple of 100ms.

OBJECT DESCRIPTION

INDEX	1015h
Name	Inhibit Time EMCY
Object Code	VAR
Data Type	UNSIGNED16
Category	Optional

ENTRY DESCRIPTION

Access	rw
PDO Mapping	No
Value Range	UNSIGNED16
Default Value	0

Object 1016h: Consumer Heartbeat Time

The consumer heartbeat time defines the expected heartbeat cycle time and thus has to be higher than the corresponding producer heartbeat time configured on the device producing this heartbeat.

Monitoring starts after the reception of the first heartbeat. If the consumer heartbeat time is 0 the corresponding entry is not used. The time has to be a multiple of 1ms.

UNSIGNED32

MSB	LSB		
Bits	31-24	23-16	15-0
Value	reserved (value: 00h)	Node-ID	heartbeat time
Encoded as	-	UNSIGNED8	UNSIGNED16

Table 62: Structure of Consumer Heartbeat Time entry

At an attempt to configure several consumer heartbeat times unequal 0 for the same Node-ID the device aborts the SDO download with abort code 0604 0043h

OBJECT DESCRIPTION

INDEX	1016h
Name	Consumer Heartbeat Time
Object Code	ARRAY
Data Type	UNSIGNED32
Category	Optional

ENTRY DESCRIPTION

Sub-Index	0h
Description	number entries
Entry Category	Mandatory
Access	ro
PDO Mapping	No
Value Range	1 - 127
Default Value	4

Sub-Index	1h
Description	Consumer Heartbeat Time
Entry Category	Mandatory
Access	rw
PDO Mapping	No
Value Range	UNSIGNED32 (Figure 62)
Default Value	0

Sub-Index	2h - 4h
Description	Consumer Heartbeat Time
Entry Category	Optional
Access	rw
PDO Mapping	No
Value Range	UNSIGNED32 (Figure 62)
Default Value	No

Object 1017h: Producer Heartbeat Time

The producer heartbeat time defines the cycle time of the heartbeat. The producer heartbeat time is 0 if it not used. The time has to be a multiple of 1ms.

OBJECT DESCRIPTION

INDEX	1017h
Name	Producer Heartbeat Time
Object Code	VAR
Data Type	UNSIGNED16
Category	Conditional; Mandatory if guarding not supported

ENTRY DESCRIPTION

Access	rw
PDO Mapping	No
Value Range	UNSIGNED16
Default Value	0

Object 1018h: Identity Object

The object at index 1018h contains general information about the device.

The Vendor ID (sub-index 1h) contains a unique value allocated to each manufacturer.

The manufacturer-specific Product code (sub-index 2h) identifies a specific device version.

The manufacturer-specific Revision number (sub-index 3h) consists of a major revision number

and a minor revision number. The major revision number identifies a specific CANopen behavior.

If the CANopen functionality is expanded, the major revision has to be incremented. The minor revision number identifies different versions with the same CANopen behavior.

31 major revision number MSB	16 15 minor revision number	0 LSB
------------------------------------	--------------------------------	----------

Structure of Revision number

The manufacturer-specific Serial number (sub-index 4h) identifies a specific device.

OBJECT DESCRIPTION

INDEX	1018h
Name	Identity Object
Object Code	RECORD
Data Type	Identity
Category	Mandatory

ENTRY DESCRIPTION

Sub-Index	0h
Description	number of entries
Entry Category	Mandatory
Access	Ro
PDO Mapping	No
Value Range	1 .. 4
Default Value	4

Sub-Index	1h
Description	Vendor ID
Entry Category	Mandatory
Access	Ro
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	0x00000141

Sub-Index	2h
Description	Product code
Entry Category	Optional
Access	Ro
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	0x00000700

Sub-Index	3h
Description	Revision number
Entry Category	Optional
Access	Ro
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	0x00010001

Sub-Index	4h
Description	Serial number
Entry Category	Optional
Access	Ro
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	No

Object 1020h: Verify Configuration

If a device supports the saving of parameters in non-volatile memory, a network configuration tool or a CANopen manager can use this object to verify the configuration after a devices reset and to check if a reconfiguration is necessary. The configuration tool shall store the date and time in that object and shall store the same values in the DCF. Now the configuration tool lets the device save its configuration by writing to index 1010h Sub-Index 1h the signature "save". After a reset the device shall restore the last configuration and the signature automatically or by request. If any other command changes boot-up configuration values, the device shall reset the object Verify Configuration to 0.

The Configuration Manager compares signature and configuration with the value from the DCF and decides if a reconfiguration is necessary or not.

Index	Object	Name	Type	Attr.	M/O
1020h	ARRAY	Verify Configuration	Unsigned32	rw	O

The sub-objects for the Verify Configuration Object are:

Index	Sub-Index	Field in Configuration Verify	Data Type
1020h	0h	Number of supported entries	Unsigned8
	1h	Configuration date	Unsigned32
	2h	Configuration time	Unsigned32

Configuration date shall contain the number of days since January 1,1984. Configuration time shall be the number of ms after midnight.

Application hint: The usage of this object allows a significant speed-up of the boot-up process. If it is used, the system integrator has to consider that a user may change a configuration value and afterwards activate the command store configuration 1010h without changing the value of 1020h. So the system integrator has to ensure a 100% consequent usage of this feature.

Object 1029: Error behavior object

If a serious device failure is detected in Operational State, the module shall enter by default autonomously the pre-operational state. If object 1028h (Error Behavior) is implemented, the device can be configured to enter alternatively the stopped state or remain in the current state in case of a device failure. Device failures shall include the following communication errors:

- Bus-off conditions of the CAN interface
- Life guarding event with the state 'occurred'
- Heartbeat event with state 'occurred'

Serious device errors also can be caused by device internal failures.

The value of the Error Classes is as follows:

0 = pre-operational (only if current state is operational)

1 = no state change

2 = stopped

3 .. 127 = reserved

OBJECT DESCRIPTION

INDEX	1029h
Name	Error Behavior
Object Code	ARRAY
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Sub-Index	0h
Description	No. of Error Classes
Entry Category	Mandatory
Access	Ro
PDO Mapping	No
Value Range	1h
Default Value	1

Sub-Index	1h
Description	Communication Error
Entry Category	Mandatory
Access	rw
PDO Mapping	No
Value Range	UNSIGNED8
Default Value	0

Object 1200h-1201h: Server SDO Parameter

In order to describe the SDOs used on a device the data type SDO Parameter is introduced. The data type has the index 22h in the Object Dictionary. The structure is described in 9.5.4.

The number of supported entries in the SDO object record is specified at sub-index 0h. The values at 1h and 2h specify the COB-ID for this SDO. Sub-index 3 gives the server of the SDO in case the record describes an SDO for which the device is client and gives the client of the SDO if the record describes an SDO for which the device is server.

UNSIGNED32					LSB
bits	31	30	29	28-11	10-0
11-bit-ID	0/1	0	0	0 0	11-bit Identifier
29-bit-ID	0/1	0	1	29-bit Identifier	

Figure 64: Structure of SDO COB-ID entry

Table 53: Description of SDO COB-ID entry

bit number	value	Meaning
31 (MSB)	0	SDO exists / is valid
	1	SDO does not exist / is not valid
30	0	reserved (always 0)
29	0	11-bit ID (CAN 2.0A)
	1	29-bit ID (CAN 2.0B)
28 – 11	0	if bit 29=0
	X	if bit 29=1: bits 28-11 of 29-bit-COB-ID
10-0 (LSB)	X	bits 10-0 of COB-ID

An SDO is only valid if both SDO-valid-bits are 0. Devices supporting the standard CAN frame type only, an attempt to set bit 29 is responded with an abort message (abort code: 0609E0030h).

These objects contain the parameters for the SDOs for which the device is the server. If a device handles more than one server SDO the default SDO must be located at index 1200h as the first server SDO. This entry is read only 2. All additional server SDOs are invalid by default (invalid bit - see Table 53), there description is located at subsequent indicies. It is not allowed to change the COB-ID while the SDO exists.

The description of the Client of the SDO (sub-index 3h) is optional. It is not available for the default SDO (no Sub-index 3h at Index 1200h), as this entry is read only.

OBJECT DESCRIPTION

INDEX	1200-1201h
Name	Server SDO parameter
Object Code	RECORD
Data Type	SDO Parameter
Category	Conditional Index 1200h: Optional Index 1201h - 127Fh: Mandatory for each additionally supported server SDO

ENTRY DESCRIPTION

Sub-Index	0h
Description	number of entries
Entry Category	Mandatory
Access	Ro
PDO Mapping	No
Value Range	Index 1200h: 2 Index 1201h - 127F: 2 – 3
Default Value	No

Sub-Index	1h
Description	COB-ID Client->Server (rx)
Entry Category	Mandatory
Access	Index 1200h: ro, Index 1201h-127Fh: rw
PDO Mapping	No
Value Range	UNSIGNED32 (Table 53)
Default Value	Index 1200h: 600h+Node-ID, Index 1201h-127Fh: No

Sub-Index	2h
Description	COB-ID Server -> Client (tx)
Entry Category	Mandatory
Access	Index 1200h: ro Index 1201-127Fh: rw
PDO Mapping	No
Value Range	UNSIGNED32 (Table 53)
Default Value	Index 1200h: 580h+Node-ID, Index 1201h-127Fh: No

Object 1400h – 141Eh: Receive PDO Communication Parameter

Contains the communication parameters for the PDOs the device is able to receive. The type of the PDO communication parameter (20h) is described in 9.5.4. The sub-index 0h contains the number of valid entries within the communication record. Its value is at least 2. If inhibit time supported the value is 3. At sub-index 1h resides the COB-ID of the PDO. This entry has been defined as UNSIGNED32 in order to cater for 11-bit CAN Identifiers (CAN 2.0A) as well as for 29-bit CAN identifiers (CAN 2.0B).

The entry has to be interpreted as defined in Figure 65 and Table 54.

UNSIGNED32

	MSB	LSB							
bits	31	30	29	28-11					10-0
11-bit-ID	0/1	0/1	0	0 0	11-bit Identifier				
29-bit-ID	0/1	0/1	1	29-bit Identifier					

Figure 65: Structure of PDO COB-ID entry

Table 54: Description of PDO COB-ID entry

bit number	value	Meaning
31 (MSB)	0	PDO exists / is valid
	1	PDO does not exist / is not valid
30	0	RTR allowed on this PDO
	1	no RTR allowed on this PDO
29	0	11-bit ID (CAN 2.0A)
	1	29-bit ID (CAN 2.0B)
28 – 11	0	if bit 29=0
	X	if bit 29=1: bits 28-11 of 29-bit-COB-ID
10-0 (LSB)	X	bits 10-0 of COB-ID

The PDO valid/not valid allows to select which PDOs are used in the operational state. There may be PDOs fully configured (e.g. by default) but not used, and therefore set to "not valid" (deleted). The feature is necessary for devices supporting more than 4 RPDOs or 4 TPDOs, because each device has only default identifiers for the first four RPDOs/TPDOs. Devices supporting the standard CAN frame type only or do not support Remote Frames, an attempt to set bit 29 to 1 or bit 30 to 0 is responded with an abort message (abort code: 0609E0030h). It is not allowed to change bit 0-29 while the PDO exists (Bit 31=0).

The transmission type (sub-index 2) defines the transmission/reception character of the PDO (see 9.2.1.1). Table 55 describes the usage of this entry. On an attempt to change the value of the transmission type to a value that is not supported by the device an abort message (abort code: 0609E0030h) is generated.

transmission type	PDO transmission				
-	Cyclic	acyclic	synchronous	asynchronous	RTR only
0	-	X	X	-	-
1-240	X	-	X	-	-
241-251	-reserved -				
252	-	-	X	-	X
253	-	-	-	X	X
254	-	-	-	X	-
255	-	-	-	X	-

Synchronous (transmission types 0-240 and 252) means that the transmission of the PDO shall be related to the SYNC object as described in 9.3. Preferably the devices use the SYNC as a trigger to output or actuate based on the previous synchronous Receive PDO respectively to

update the data transmitted at the following synchronous Transmit PDO. Details of this mechanism depend on the device type and are defined in the device profile if applicable. Asynchronous means that the transmission of the PDO is not related to the SYNC object. A transmission type of zero means that the message shall be transmitted synchronously with the SYNC object but not periodically.

A value between 1 and 240 means that the PDO is transferred synchronously and cyclically. The transmission type indicating the number of SYNC which are necessary to trigger PDO transmissions.

Receive PDOs are always triggered by the following SYNC upon reception of data independent of the transmission types 0 - 240.

The transmission types 252 and 253 mean that the PDO is only transmitted on remote transmission request. At transmission type 252, the data is updated (but not sent) immediately after reception of the SYNC object. At transmission type 253 the data is updated at the reception of the remote transmission request (hardware and software restrictions may apply). These values are only possible for TPDOs.

For TPDOs transmission type 254 means, the application event is manufacturer specific (manufacturer specific part of the Object Dictionary), transmission type 255 means, the application event is defined in the device profile. RPDOs with that type trigger the update of the mapped data with the reception.

Sub-index 3h contains the inhibit time. This time is a minimum interval for PDO transmission. The value is defined as multiple of 100ms. It is not allowed to change the value while the PDO exists (Bit 31 of sub-index 1 is 0).

Sub-index 4h is reserved. It does not have to be implemented, in this case read or write access leads to Abort SDO Transfer (abort code: 0609 0011h).

In mode 254/255 additionally an event time can be used for TPDO. If an event timer exists for a TPDO (value not equal to 0) the elapsed timer is considered to be an event. The event timer elapses as multiple of 1 ms of the entry in sub-index 5h of the TPDO. This event will cause the transmission of this TPDO in addition to otherwise defined events. The occurrence of the events set the timer. Independent of the transmission type the RPDO event timer is used to recognize the expiration of the RPDO.

OBJECT DESCRIPTION

INDEX	1400h – 141Fh
Name	receive PDO parameter
Object Code	RECORD
Data Type	PDO CommPar
Category	Conditional; Mandatory for each supported PDO

ENTRY DESCRIPTION

Sub-Index	0h
Description	largest sub-index supported
Entry Category	Mandatory
Access	ro
PDO Mapping	No
Value Range	2 – 5

Sub-Index	1h
Description	COB-ID used by PDO
Entry Category	Mandatory
Access	ro; rw if variable COB-ID is supported
PDO Mapping	No
Value Range	UNSIGNED32 (Table 54)
Default Value	Index 1400h: 200h + Node-ID, Index 1401h: 300h + Node-ID, Index 1402h: 400h + Node-ID, Index 1403h: 500h + Node-ID, Index 1404h – 15FFh: disabled

Sub-Index	2h
Description	transmission type
Entry Category	Mandatory
Access	ro;rw if variable transmission type is supported
PDO Mapping	No
Value Range	UNSIGNED8 (Table 55)
Default Value	(Device Profile dependent)

Sub-Index	3h
Description	inhibit time (not used for RPDO)
Entry Category	Optional
Access	rw
PDO Mapping	No
Value Range	UNSIGNED16
Default Value	No

Sub-Index	4h
Description	compatibility entry
Entry Category	Optional
Access	rw
PDO Mapping	No
Value Range	UNSIGNED8
Default Value	No

Sub-Index	5h
Description	event timer

Entry Category	Optional (not used for RPDO)
Access	rw
PDO Mapping	No
Value Range	0 = not used UNSIGNED16
Default Value	No

Object 1600h – 161Eh: Receive PDO Mapping Parameter

Contains the mapping for the PDOs the device is able to receive. The type of the PDO mapping parameter (21h) is described in 9.5.4. The sub-index 0h contains the number of valid entries within the mapping record. This number of entries is also the number of the application variables which shall be transmitted/received with the corresponding PDO. The sub-indices from 1h to number of entries contain the information about the mapped application variables. These entries describe the PDO contents by their index, sub-index and length (Figure 66). All three values are hexadecimal coded. The length entry contains the length of the object in bit (1..40h). This parameter can be used to verify the overall mapping length. It is mandatory.

The structure of the entries from sub-index 1h - 40h is as follows:

Byte: MSB	index (16 bit)	sub-index (8 bit)	object length (8 bit)	LSB

Figure 66: Structure of PDO Mapping Entry

If the change of the PDO mapping cannot be executed (e.g. the PDO length is exceeded or the SDO client attempts to map an object that cannot be mapped) the device responds with an Abort SDO Transfer Service.

Subindex 0 determines the valid number of objects that have been mapped. For changing the PDO mapping first the PDO has to be deleted, the sub-index 0 must be set to 0 (mapping is deactivated). Then the objects can be remapped. When a new object is mapped by writing a subindex between 1 and 64, the device may check whether the object specified by index / sub-index exists. If the object does not exist or the object cannot be mapped, the SDO transfer must be aborted with the Abort SDO Transfer Service with one of the abort codes 0602 0000h or 0604 0041h. After all objects are mapped subindex 0 is set to the valid number of mapped objects.

Finally the PDO will be created by writing to its communication parameter COB-ID. When subindex 0 is set to a value >0 the device may validate the new PDO mapping before transmitting the response of the SDO service. If an error is detected the device has to transmit the Abort SDO Transfer Service with one of the abort codes 0602 0000h, 0604 0041h or 0604 0042h.

When subindex 0 is read the actual number of valid mapped objects is returned.

If data types (Index 1h-7h) are mapped they serve as “dummy entries”. The corresponding data in the PDO is not evaluated by the device. This optional feature is useful e.g. to transmit data to several devices using one PDO, each device only utilizing a part of the PDO. It is not possible to create a dummy mapping for a TPDO.

OBJECT DESCRIPTION

INDEX	1600h – 161Fh
Name	receive PDO mapping
Object Code	RECORD
Data Type	PDO Mapping
Category	Conditional; Mandatory for each supported PDO

ENTRY DESCRIPTION

Sub-Index	0h
Description	number of mapped application objects in PDO
Entry Category	Mandatory
Access	ro; rw if dynamic mapping is supported
PDO Mapping	No
Value Range	0: deactivated 1 - 64: activated
Default Value	(device profile dependent)

Sub-Index	1h - 40h
Description	PDO mapping for the nth application object to be mapped
Entry Category	Conditional depends on number and size of object be mapped
Access	rw
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	(device profile dependent)

Object 1800h – 181Fh: Transmit PDO Communication Parameter

Contains the communication parameters for the PDOs the device is able to transmit. The type of the PDO communication parameter (20h) is described in 9.5.4. A detailed description of the entries is done in the section for the Receive PDO Communication Parameter (1400h – 141Fh).

OBJECT DESCRIPTION

INDEX	1800h – 181Fh
Name	transmit PDO parameter
Object Code	RECORD
Data Type	PDO CommPar
Category	Conditional; Mandatory for each supported PDO

ENTRY DESCRIPTION

Sub-Index	0h
Description	largest sub-index supported
Entry Category	Mandatory
Access	ro
PDO Mapping	No
Value Range	2 – 5

Sub-Index	1h
Description	COB-ID used by PDO
Entry Category	Mandatory
Access	ro; rw if COB-ID can be configured
PDO Mapping	No
Value Range	UNSIGNED32 (Figure 65)
Default Value	Index 1800h: 180h + Node-ID, Index 1801h: 280h + Node-ID, Index 1802h: 380h + Node-ID, Index 1803h: 480h + Node-ID, Index 1804h - 18FFh: disabled

Sub-Index	2h
Description	transmission type
Entry Category	Mandatory
Access	ro; rw if transmission type can be changed
PDO Mapping	No
Value Range	UNSIGNED8 (Table 54)
Default Value	(device profile dependent)

Sub-Index	3h
Description	inhibit time
Entry Category	Optional
Access	rw
PDO Mapping	No
Value Range	UNSIGNED16
Default Value	No

Sub-Index	4h
-----------	----

Description	reserved
Entry Category	Optional
Access	rw
PDO Mapping	No
Value Range	UNSIGNED8
Default Value	No

Sub-Index	5h
Description	event timer
Entry Category	Optional
Access	rw
PDO Mapping	No
Value Range	0 = not used UNSIGNED16
Default Value	No

Object 1A00h – 1A1Fh: Transmit PDO Mapping Parameter

Contains the mapping for the PDOs the device is able to transmit. The type of the PDO mapping parameter (21h) is described in 9.5.4. A detailed description of the entries is done in the section for the Receive PDO Mapping Parameter (1600h – 161Fh).

OBJECT DESCRIPTION

INDEX	1A00h – 1A1Fh
Name	transmit PDO mapping
Object Code	RECORD
Data Type	PDO Mapping
Category	Conditional; Mandatory for each supported PDO

ENTRY DESCRIPTION


Sub-Index	0h
Description	number of mapped application objects in PDO
Entry Category	Mandatory
Access	ro; rw if dynamic mapping is supported
PDO Mapping	No
Value Range	0: deactivated 1 - 64: activated
Default Value	(device profile dependent)

Sub-Index	1h - 40h
Description	PDO mapping for the n-th application object to be mapped
Entry Category	Conditional; depends on number and size of objects to be mapped
Access	Rw
PDO Mapping	No
Value Range	UNSIGNED32
Default Value	(device profile dependent)

Multiplexed PDOs

MPDO Protocol

This protocol is used to implement MPDO services. The MPDO producer sends data and the multiplexor indicating the source or destination address.



Byte	0	1-3	4-8
Meaning	f	Addr	m D

'd' shall contain the data to be transferred. The value always shall be filled up to 32 bit. 3
'm' shall contain the multiplexor (Index and Sub-Index) of the variable in the object dictionary.
The MSB 'f' of the first byte shall be a format flag, and 'addr' shall be an address field, which may
be used in the following combinations:

f	addr	Usage
0	0	Reserved
0	1-127	Source addressing. addr is a single producer's Node ID. Multiplexor is index and sub-index of the object dictionary of the producer.
1	0	Destination addressing. The consumer is a group.
1	1-127	Destination addressing. addr is a single consumer's Node ID. Multiplexor is index and sub-index of the object dictionary of the consumer.

Destination Address Mode (DAM)

The *addr* and the *m* field of the MPDO refers to the consumer. This allows access to the consumer's Object Dictionary in an SDO-like manner. With *addr* = 0, it allows multicasting and broadcasting, to write into the Object Dictionaries of more than one node simultaneously, without having a PDO for each single object.

Initiating a DAM-MPDO is application-dependent, like it is for SDOs.

Source Address Mode (SAM)

The *addr* and the *m* field of the MPDO refers to the producer. Only one producer MPDO of this type is allowed for each node.

Transmission type has to be 254 or 255.

The producer uses an Object Scanner List in order to know, which objects are to send. The consumer uses an Object Dispatcher List as a 'cross reference'. The restriction about using 32-bit transfers only will not present problems in practice since all of the participating devices know the data types (and sizes) of their related objects.

Object dictionary entries

PDO Mapping Record

The meaning of Sub-Index 0 (number of mapped objects) is extended. The valid range for non-multiplexed PDOs is 0 to 64. A value of 255 indicates a DAM-MPDO, a value of 254 indicates an SAM-MPDO.

For SAM, the further entries in the MR are don't care.

For DAM the first object describes the local object (there can be mapped only one object into an MPDO).

Index	Object	Name	Type
16XXh-1AXXh	0h	Number of mapped objects in the PDO: 0 .. 64: Valid range for number of mapped objects 254: formatted as SAM- MPDO 255: formatted as DAM- MPDO	Unsigned 8

This leaves open the possibility for further alternative PDO formats.

Additional error code meanings

Error Code Meaning
TBD

Predefinitions

Introduction

All TPDOs with transmission type 255 shall be transmitted when entering the OPERATIONAL state.

PDO Mapping

6.2.1 1st RPDO mapping (Memory Access)

This RPDO receives asynchronously the objects that control the memory module access. The default transmission type shall be 255. The default values of the mapped outputs are described in the Default State objects. *Note:* After power-on and application reset these default objects are valid.

Index	Sub-Index	Comment	Default Value
1600h	0h	number of mapped objects	1
1600h	1h	1st object to be mapped	3110 00 40h

6.2.2 1st TPDO mapping (Memory Access)

The default transmission type shall be 255; the default values for inhibit and event timer are 0. If one of the values changes its value, this PDO shall be transmitted immediately.

Index	Sub-Index	Comment	Default Value
1A00h	0h	number of mapped objects	1
1A00h	1h	1st object to be mapped	3111 00 40h

Manufacturer Specific Objects

Overview:

RTC Objects

Index (hex)	Object (Symbolic Name)	Name	Type	Access	I/O MAP	NV
2000	VAR	Time of Day	TIME_OF_DAY	Ro	N	V
2001	VAR	Time/Date (Reserved)	UNSIGNED16	Ro	N	V
2002	VAR	Time String	VISIBLE STRING	Ro	N	V
2003	VAR	Date String	VISIBLE STRING	Ro	N	V
2004	VAR	Time String Format	UNSIGNED8	Ro	N	NV
2005	VAR	Date String Format	UNSIGNED8	Ro	N	NV

Memory Objects

Index (hex)	Object (Symbolic Name)	Name	Type	Access	I/O MAP	NV
3000	VAR	Memory Erase	UNSIGNED32	Rw	N	NV
3001	VAR	Memory Write	OCTET_STRING	Rw	N	NV
3002	VAR	Memory Read	OCTET_STRING	Ro	N	V
3003	VAR	Memory Reset Read Pointer	UNSIGNED8	Rw	N	V
3004	VAR	Memory Store Mode	UNSIGNED8	Rw	N	NV
3005	VAR	Memory Delimiter	UNSIGNED8	Rw	N	NV
3006	VAR	Memory Fixed Length	UNSIGNED8	Rw	N	NV
3007	VAR	Memory AutoStamp Format	UNSIGNED8	Rw	N	NV
3008	VAR	Memory Blank	UNSIGNED8	Ro	N	V
3010	VAR	Memory Request Fragment	MEM_FRAGMENT	Rww	Y	V
3011	VAR	Memory Response Fragment	MEM_FRAGMENT	Rwr	Y	V

CANopen Objects

Index (hex)	Object (Symbolic Name)	Name	Type	Access	I/O MAP	NV
4000	VAR	CANopen Baud	UNSIGNED32	Rw	N	NV
4001	VAR	CANopen NodeID	UNSIGNED8	Rw	N	NV

Manufacturer Specific Object Details:

RTC Objects

Object 2000h: Time Of Day

This object provides the actual time of day in the CANopen TIME_OF_DAY format.

OBJECT DESCRIPTION

INDEX	2000h
Name	Time of Day
Object Code	VAR
Data Type	TIME_OF_DAY
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	TIME_OF_DAY
Default Value	no

Object 2001h: Time Date (Reserved for Future Use)

This object provides the actual time of day in a format TBD.

OBJECT DESCRIPTION

INDEX	2001h
Name	Time Date
Object Code	VAR
Data Type	TBD
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	TBD
Default Value	No

Object 2002h: Time String

This object provides the actual time of day in a visible string format.

OBJECT DESCRIPTION

INDEX	2002h
Name	Time of Day
Object Code	VAR
Data Type	VISIBLE_STRING
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	VISIBLE_STRING
Default Value	No

The format of the Time string is determined by the Time String Format Object. Please see that object for a description.

Object 2003h: Date String

This object provides the actual date in a visible string format.

OBJECT DESCRIPTION

INDEX	2003h
Name	Date String
Object Code	VAR
Data Type	VISIBLE_STRING
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	VISIBLE_STRING
Default Value	No

The format of the Date String is determined by the Date String Format Object. Please see that object for a description.

Object 2004h: Time String Format

This object provides a means to set the format for the Time String Object.

OBJECT DESCRIPTION

INDEX	2004h
Name	Time String Format
Object Code	VAR
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	0,1
Default Value	No

The format of the Time string is determined by the Time String Format Object.

0 = "HH:MM:SS"

1 = "HHMMSS"

Object 2005h: Date String Format

This object provides a means to set the format for the Date String Object.

OBJECT DESCRIPTION

INDEX	2005h
Name	Date String Format
Object Code	VAR
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	0-3
Default Value	No

The format of the Dime String is determined by the Dime String Format Object.

0 = "YY/MM/DD"

1 = "MM/DD/YYYY"

2 = "YYYYMMDD"

3 = "MMDDYYYY"

Memory Objects

Object 3000h: Memory Erase

This object provides a means for erasing the stored data in the memory module.

OBJECT DESCRIPTION

INDEX	3000h
Name	Memory Module Erase
Object Code	VAR
Data Type	UNSIGNED32
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	0,0x44332211
Default Value	No

Writing a value of 0x44332211 causes the Memory Module to be erased. The value is read back until it is erased, then it is read as 0.

Object 3001h: Memory Write

This object provides a means for writing data to the memory module.

OBJECT DESCRIPTION

INDEX	3001h
Name	Memory Module Write
Object Code	VAR
Data Type	OCTET_STRING
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	
Default Value	No

The data written to this object is stored in the Memory Module. After storing, the internal file pointer is incremented to the end of the data written. In fixed mode, if the data length is less than the fixed length size, the additional space is padded with 0xFF. In Delimiter mode, the data is appended with the user defined delimiter character.

Object 3002h: Memory Read

This object provides a means for reading data out of the memory module.

OBJECT DESCRIPTION

INDEX	3002h
Name	Memory Module Read
Object Code	VAR
Data Type	OCTET_STRING
Category	Optional

ENTRY DESCRIPTION

Access	Ro
PDO Mapping	No
Value Range	
Default Value	No

Reading this object reads out any stored information in the memory module. If Delimiter mode is used, the length of data that is returned is the count of bytes up to the delimiter character. If the Fixed length mode is used, the length of the data returned is equal to fixed size. If no data has been written, the object returns a zero length packet. After reading, the internal file pointer is incremented to the next available data. The user can use the Memory Module Read Reset to adjust the pointer back to the beginning.

Object 3003h: Memory Read Reset

This object provides a means for resetting the internal read pointer back to the beginning.

OBJECT DESCRIPTION

INDEX	3003h
Name	Memory Read Reset
Object Code	VAR
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	0,1
Default Value	No

Writing a value of 1 resets the read pointer to the beginning of the stored data.

Object 3004h: Memory Store Mode

This object provides a means for setting the store mode for the Memory Module.

OBJECT DESCRIPTION

INDEX	3004h
Name	Memory Store Mode
Object Code	VAR
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	0,1
Default Value	0

0 = Fixed Write Length

1 = Delimiter Appended Writes

If delimiter mode is used, the data written to the write object is appended with the delimiter character.

If fixed length mode is used, the data is written up to the fixed size. If less data is sent the data is padded with 0xff.

Object 3005h: Memory Delimiter

This object provides a means for setting the delimiter to be used in Delimiter Store Mode.

OBJECT DESCRIPTION

INDEX	3005h
Name	Memory Delimiter
Object Code	VAR
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	UNSIGNED8
Default Value	0x2C =(ASCII comma)

The Memory Delimiter is appended to the write data when the Delimiter Store Mode is used.

Object 3006h: Memory Fixed Length

This object provides a means for setting the fixed length size. This value sets the maximum size of the data packets to be stored.

OBJECT DESCRIPTION

INDEX	3006h
Name	Memory Fixed Length
Object Code	VAR
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	0-80
Default Value	80

The value of the Fixed Length determines how many bytes are written each time that a user does a write to the write data object. If less bytes are sent, the additional space is padded with 0xFF.

Object 3007h: Memory AutoStamp Format

This object provides a means for setting the auto time/date stamp used in the memory module.

OBJECT DESCRIPTION

INDEX	3007h
Name	Memory AutoStamp Format
Object Code	VAR
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	0-12
Default Value	No

The AutoStamp format allows the user to configure the memory module to automatically time and date stamp the data written to the write data object.

- 0 = No Time/Date Stamp
- 1 = "YYYY/MM/DD HH:MM:SS "
- 2 = "MM/DD/YYYY HH:MM:SS "
- 3 = "YYYYMMDD HHMMSS "
- 4 = "MMDDYYYY HHMMSS "
- 5 = "YYYYMMDDHHMMSS"
- 6 = "MMDDYYYYHHMMSS"
- 7 = "HH:MM:SS YYYY/MM/DD "
- 8 = "HH:MM:SS MM/DD/YYYY "
- 9 = "HHMMSS YYYYMMDD "
- 10 = "HHMMSS MMDDYYYY "
- 11 = "HHMMSSYYYYMMDD"
- 12 = "HHMMSSMMDDYYYY"

Object 3008h: Memory Blank

This object provides a means for the user to determine if the memory module is blank.

OBJECT DESCRIPTION

INDEX	3008h
Name	Memory Blank
Object Code	VAR
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Access	Ro
PDO Mapping	No
Value Range	0,1
Default Value	No

0=Not Blank

1=Blank

Object 3010h: Memory Request Fragment (Reserved)

This object provides a means for the user to read from or write to the memory module using PDOs.

OBJECT DESCRIPTION

INDEX	3010h
Name	Memory Request Fragment
Object Code	VAR
Data Type	MEMORY_REQUEST_FRAGMENT
Category	Optional

ENTRY DESCRIPTION

Access	Rww
PDO Mapping	Yes
Value Range	
Default Value	No

Reserved for future use.

Object 3011h: Memory Response Fragment (Reserved)

This object provides a means for the user to read from or write to the memory module using PDOs.

OBJECT DESCRIPTION

INDEX	3011h
Name	Memory Response Fragment
Object Code	VAR
Data Type	MEMORY_RESPONSE_FRAGMENT
Category	Optional

ENTRY DESCRIPTION

Access	Ro
PDO Mapping	Yes
Value Range	
Default Value	No

Reserved for future use.

Object 3012h: Memory Overwrite Mode

This object provides a means for setting the internal overwrite mode for the Memory Module.

OBJECT DESCRIPTION

INDEX	3012h
Name	Memory Overwrite Mode
Object Code	VAR
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	0,1
Default Value	0

0 = No overwrite

1 = Ring Buffer

When the ring buffer mode is used the oldest data is overwritten when more data is written after the module is full. When the no overwrite mode is used, the module will return an error if the user tries to write data to the module after the internal memory is full.

Object 3013h: Memory Bytes Written

This object provides a means for determining how many bytes have been written to the internal memory.

OBJECT DESCRIPTION

INDEX	3013h
Name	Memory Bytes Written
Object Code	VAR
Data Type	UNSIGNED32
Category	Optional

ENTRY DESCRIPTION

Access	Ro
PDO Mapping	No
Value Range	0-393215
Default Value	No

The Value read is the number of bytes that have been written to the internal memory.

Object 3014h: Memory Bytes Free

This object provides a means for determining how many bytes are available in the internal memory.

OBJECT DESCRIPTION

INDEX	3014h
Name	Memory Bytes Free
Object Code	VAR
Data Type	UNSIGNED32
Category	Optional

ENTRY DESCRIPTION

Access	Ro
PDO Mapping	No
Value Range	0-393215
Default Value	No

The Value read is the number of bytes that are free before the memory module is full. If the user chooses the ring buffer mode, the value will indicate the number of bytes until data will be lost.

Object 3020h: Write Time/Date Stamp to Memory

This object provides a means for stamping the current time/date to the internal memory.

OBJECT DESCRIPTION

INDEX	3020h
Name	Write Time Date
Object Code	VAR
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	0-12
Default Value	No

The Write Time Date format allows the user to write the time/date to the internal memory by simply writing the format the user wishes to stamp.

- 0 = No Time/Date Stamp
- 1 = "YYYY/MM/DD HH:MM:SS "
- 2 = "MM/DD/YYYY HH:MM:SS "
- 3 = "YYYYMMDD HHMMSS "
- 4 = "MMDDYYYY HHMMSS "
- 5 = "YYYYMMDDHHMMSS"
- 6 = "MMDDYYYYHHMMSS"
- 7 = "HH:MM:SS YYYY/MM/DD "
- 8 = "HH:MM:SS MM/DD/YYYY "
- 9 = "HHMMSS YYYYMMDD "
- 10 = "HHMMSS MMDDYYYY "
- 11 = "HHMMSSYYYYMMDD"
- 12 = "HHMMSSMMDDYYYY"

CANopen Objects

Object 4000h: CANopen Baud Rate

This object provides a means for setting the CANopen baud rate.

OBJECT DESCRIPTION

INDEX	4000h
Name	CANopen Baud Rate
Object Code	VAR
Data Type	UNSIGNED32
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	(see below)
Default Value	250000

The new baud rate becomes effective after a module rest or power cycle.

Values Supported.

10000
20000
50000
100000
125000
250000
500000
1000000

Object 4001h: CANopen NodeID

This object provides a means for setting the CANopen NodeID.

OBJECT DESCRIPTION

INDEX	4001h
Name	CANopen NodeID
Object Code	VAR
Data Type	UNSIGNED8
Category	Optional

ENTRY DESCRIPTION

Access	Rw
PDO Mapping	No
Value Range	1-127
Default Value	5

The new NodeID becomes effective after a module rest or power cycle.